

# FREQUENCY CHART

## 80M BAND ( 3.5~4 MHz ) ( JUMPER LEAD IS NOT NEEDED)

Freq.(MHz)	3.5	3.625	3.75	3.875	4
LENGTH (mm)	1760	1635	1510	1395	1300

## 40M BAND ( 7~7.3 MHz ) (JUMPER LEAD P1 TO P2 )

Freq.(MHz)	7	7.075	7.15	7.225	7.3
LENGTH (mm)	1760	1760	1715	1665	1620

## 20M BAND ( 14~14.35 MHz ) (JUMPER LEAD P1 TO P3 )

Freq.(MHz)	14	14.075	14.15	14.25	14.35
LENGTH (mm)	1735	1735	1695	1695	1655

## 15M BAND ( 21~21.45 MHz ) (JUMPER LEAD P1 TO P4 )

Freq.(MHz)	21	21.1	21.2	21.325	21.45
LENGTH (mm)	1850	1850	1850	1850	1850

## 10M BAND ( 28~29.7 MHz ) (JUMPER LEAD P1 TO P5 )

Freq.(MHz)	28	28.15	28.3	29	29.7
LENGTH (mm)	1800	1800	1780	1715	1675

## 6M BAND ( 50~54 MHz ) (JUMPER LEAD P1 TO P6 )

Freq.(MHz)	50	50.1	51.4	52.7	54
LENGTH (mm)	1475	1475	1410	1375	1355

## 2M BAND ( 144~148 MHz ) (JUMPER LEAD P1 TO P6 )

Freq.(MHz)	144	146	148		
LENGTH (mm)	1420	1420	1400		

## 70cm BAND ( 420~450 MHz ) (JUMPER LEAD P1 TO P6 )

Freq.(MHz)	420	430	440	450	
LENGTH (mm)	1440	1410	1365	1355	

## AIR BAND (118-136 MHz) (JUMPER LEAD P1 TO P6 )

Freq.(MHz)	118	127	136		
LENGTH (mm)	1760	1620	1510		